# BVPI 84a – Number of kilograms of household waste collected per head of population

What the indicator measures:

Numerator

Denominator

$$\frac{\text{Total tonnage of household waste arisings}}{\text{Population in authority area}} \times 1000$$

How the numerator and denominator are calculated using WasteDataFlow is summarised below setting out the questions data are drawn from.

Numerator

1. Total tonnage of household waste collected for recycling from Q10, Q12, Q16, Q17, Q18 (household waste column), Q33 and Q34	→ Excludes rubble and re-use. Material rejected is not deducted as this is part of the total household waste arisings.

+

2. Total tonnage of residual household waste from Q23	→ All collected household waste, CA site household, separately collected healthcare waste & gully emptyings.

Denominator

1.Population in authority area from Q1	→ Information is based on Office of National Statistics mid-year figures for population & is updated annually.