Kpi (h) - Total household waste collected per household

What the indicator measures:

Numerator Total tonnage of household waste arisings

Denominator Total number of households in authority area

How the numerator and denominator are calculated using WasteDataFlow is summarised below setting out the questions data are drawn from.

Numerator

1. Total tonnage of household waste collected for recycling from Q10, Q12, Q16, Q17, Q18 (household waste column), Q33 and Q34

Excludes rubble.

Material rejected is not deducted as this is part of the total household waste arisings.

All collected household residual waste.

Denominator

